

# All Terrain Ultra Slim

## QUICK STEP- installation



1. Open the shoe wide.



2. Place the shoe on the hoof. Make sure that the toe is all the way in front of the shoe, and that the shoe is centered in the back



3. Put the Velcro together on both sides. Make sure to tuck both sides in, to optimize the fit of the upper part.



4. Fasten the strap in the back by pulling it through both rings, before pulling it back through the last ring.



5. Pull strap to tighten. Secure the strap by pulling it through the loop.



6. Tighten the lock in front by pulling the strap. Use a hoof pick to secure the strap. Ready to run!

